

QUICK START

Model HF-801A - (KIT 1-Gen2)

REQUIRED BEFORE INSTALLATION

Before installing extension ground wires, plug speaker DIRECTLY to base station, pair headset, and get yourself familiar with the equipment first!



You might experience echoes between headset and speaker now during testing. It is normal. Once the speaker is far away from headset, echoes will disappear.

1

Connect substation (outside loud speaker) to OUT on master station, using extension wires (provided). Plug power transformer to POWER on POS master station.

2

Plug POWER SUPPLY to POWER on MASTER STATION, turn on MASTER STATION. The system is ready to use.

RECORD (OPTIONAL)

Connect digital recording system (optional) to jack 12(REC) to record, where law permits.

SETUP GUIDE

1

Install master station and substation. Plug the substation wire into the jack 10 (OUT).

2

Connect the power transformer to an 110V power source and to the power jack 13 (POWER).

3

Press the power switch 7 to turn on the power indicator light 8; the unit is in normal working mode.

4

Press Internal microphone MIC1 push button 5 and external microphone MIC2 push button 6. The two green lights indicate a two-way duplex communication is now established.

