


# REQUIRED EQUIPMENT

## VEHICLE DETECTOR



### HOW TO SETUP YOUR VEHICLE DETECTOR



#### TRANSMITTER

Sends signal to indoor receiver

#### DRIVEWAY SENSOR

ONLY detects vehicles



#### INDOOR RECEIVER

Chime announces the arrival of a vehicle in the driveway

### DETROIT HUAFONE TECHNOLOGY LLC

An Advanced Communication Equipment Manufacturer  
Audio | Video | Wired | Wireless | Analog | IP Network

Sales and Customer Care Center  
[www.huafone.com](http://www.huafone.com) | [sales@huafone.com](mailto:sales@huafone.com)  
(800) 886-5607




# VEHICLE DETECTOR

## E-M TYPE CONFIGURATIONS

### Configuration 1

Straight driveway



## DETROIT HUAFONE TECHNOLOGY

An Advanced Communication Equipment Manufacturer

Audio | Video | Wired | Wireless | Analog | IP Network | Service

[www.huafone.com](http://www.huafone.com)

DETROIT  
**HUAFONE**


# VEHICLE DETECTOR

## E-M TYPE CONFIGURATIONS

### Configuration 2

#### Curved driveway

If the sensor has to be installed on a curved driveway install it on the inside curve as shown in the illustration.



## DETROIT HUAFONE TECHNOLOGY

An Advanced Communication Equipment Manufacturer

Audio | Video | Wired | Wireless | Analog | IP Network | Service

[www.huafone.com](http://www.huafone.com)

DETROIT  
**HUAFONE**